


**SAGUARO
SCUBA**

www.saguaroscuba.com

BACKPLATE & HARNESS

SIZING GUIDE



BACKPLATE SIZING

STEP 1 • Determine whether you need a standard back plate or add Extenda Plate extension plates.

A • Measure from the small of your back or top of hips (where your belt is most comfortably worn) to the bottom of neck or top of shoulders.

B • Use your measurement to determine which backplate you need.

>16" - 18" = STANDARD BACKPLATE


>19" = ADD EXTENDA PLATES FOR A PERFECT FIT

HARNESS SIZING

STEP 2 • Determine the correct Harness sizing:

A • Measure from the small of the back (where you want your waist belt to comfortably worn), over the shoulder, to 1in (2.5cm) above the nipple line for men, or the bust line for women (this will be the termination point of the shoulder pad).

B • Use this measurement to determine the correct size on the charts below Use the chart that corresponds to the backplate size you determined in step 1.



Every size has a range of adjustability. Transpacs are shipped adjusted to approximately the center of these ranges and can be shortened or lengthened to accommodate anyone within the range. There is some overlap of the ranges. If you fall towards the edge of one size range, it is recommended to go up or down a size so that you are closer to the center of the range to allow for more adjustability.

BACKPLATE SIZE	BACK LENGTH
Standard plate	16" - 18"
Position 1	19" - 20"
Position 2	21" - 22"
Position 3	23" - 24"
Position 4	25" - 26"

BACKPLATE SIZE	BACK LENGTH
Position 5	27" - 28"
Position 6	29" - 30"
Position 7	31" - 32"
Position 8	33" - 34"

HARNESS SIZE	
MD	26" - 28"
L	29" - 30"
XL	31" - 33"
XXL	>34"